

LZPT

ZERO PLENUM® TROFFER / LED

INSTALLATION INSTRUCTIONS



STEP 1

Slip one end of the LZPT fixture over the top of the tee. Raise the other end of the fixture into the plenum just above the bottom of the tee. Slide the fixture back into place, resting it on the inside surface of the tees.



STEP 2

The LZPT fixture is shipped with the telescoping housing in its compressed state. When installed as directed in Step 1, the fixture is less than 23" wide (less than 11" for 1 × 4s) allowing it to slide between the tees. Note that there is a temporary gap along the side of the fixture while it's still in its compressed state.



STEP 3

Apply pressure on each side of the fixture expanding it to its full 24" width (12" for 1 × 4s). Once expanded, the LZPT housing locks into position and can only be compressed again by pushing on the locking tab with a screwdriver or similar tool.

LSR INSTALLATION

STEP 1

Place lens with overlay under LZPT fixture. Move opposite edge of lens towards the retaining clips until they are inserted into the open slot along the side of the lens.

STEP 2

Once engaged with both retaining clips, bring free side up to the remaining retaining clips.

STEP 3

For the LZPT22, with fingers approximately 6" in from each end of the fixture (for the LZPT24, place fingers approximately 12" in from each end), apply slight pressure away from you and upward to install the lens and attach to the retaining clips.

STEP 4

Once the retaining clips are inserted into the slot along the edge of the lens, the installation is complete.